



P.O. B o x 785 Sebastopol, CA 95473

Install Guide for Swing Stand

Site-provided surfaced cedar 6x6 posts (5-1/2"). Set set into grade w/concrete or surface brackets to a concrete footing. Posts are set according the drawings and cut to height.

There are four mounting caps, or aprons, shipped separately. Once the posts are set and in place, to accommodate any variance in the post settings, these post aprons should slip over the top of the posts prior to setting the arbor assembly in place.

The arbor assembly lifts as a unit (Approx 80 lbs), to seat itself on top of the posts. Once the assembly is aligned, the post aprons can be mounted to the underside of the arbor assembly using the pre-bored holes using the provided small-head screws.

The arbor has been pre-bored to accept the provided lags that mount through the arbor and into the posts.

Set the two flanking panels between the end posts, centering between the posts and mounting with standard coated or exterior 4" #8 grabbers. The vertical panel stiles have been pre-bored. 2" clearance at the bottom.

Mount the optional swivel brackets to the underside of the cross-beams with site— provided lags, following the sketch suggestions to approximately 1-1/2" out from each edge of the swing. (e.g. a 60" swing will have brackets mounted at 63" apart)

The green coated chain is oriented as per the sketch, with the galvanized chain connecting the coated chain to the heavy-duty springs.

Be sure to connect the green chain as per the sketch on the swing to avoid a tipping swing.